

NICEMAY

Shenzhen Hongwang Nicemay Electric Co., Ltd.

Name: WOMEN FACIAL HAIR REMOVER

Model number: QM-2066

Whole machine: 29.7x26.2x112.2mm (L x W x H)

standard: GB 4706.1-2005

Manufacturer: Shenzhen Hongwang Nicemay Electric Co., Ltd.

Address: No.3, Lane 3, Jiajitang No.1 Industrial Zone, Gongming Town, Guangming New District, Shenzhen City, China 518132

Tel: +86-755-26552799

Place of origin: Shenzhen, China



Do not use if the blade mesh is broken.

Do not use in high temperature environment.

If the device is hit or dropped to the ground heavily, please check before using.

7

Cleansing

Please take off the blade mesh and clean hair storage area with cleansing brush carefully after using.

Please clean the blade mesh separately and do not install until it ' s dry.

Do not flush the whole device or immerse it in the water.

Storage

Do not immerse the device in high temperature environment.

Please keep away from corrosive liquid.

Please keep it out of reach of children.


8

FAQ

Q	A	Solution
The device doesn ' t work or work Intermittently.	1. Low battery 2. Too much hair in hair storage area.	1. Change to a new battery. 2. Take off the blade mesh and clean carefully.
The device stops to work suddenly.	1. Out of battery power. 2. Uncertain malfunction.	1. Change to a new battery. 2. If there is no response, please apply for after-sales service.

9


Circuit Diagram



Circuit Diagram for reference only

10

NICEMAY



QM-2066

WOMEN FACIAL HAIR REMOVER

Please read the user manual carefully before use

► Contents

Contents	1
Specifications	2
Parts Descriptions	2/3
Functions	3
Indications	4
How to Use	4/5
Safety Precautions	6/7/8
FAQ	9
Circuit Diagram	10


1

► Technical Specification

No.	Item	Unit	Spec.
1	Rated Operation Voltage	V	DC 1.5V
2	Rated Operation Current	mA	≤650mA
3	Waterproof Grade	/	IPX6
4	Power supply	/	1×AA battery (1x1.5V)

► Parts Description


- ① Magnetic cover ② LED light
 ③ Blade mesh assembly area (Rotation switch)
 ④ Hair storage area ⑤ Battery compartment
 ⑥ Cleansing brush




2

Installation Instructions

- Rotate the blade mesh clockwise to put it on for using.
 Rotate the blade mesh counter clockwise to take it off for cleansing.



- Put out the device and put into 1pc AA battery and then fit together.



► Functions


QM-2066 Women Facial Hair Remover is special designed for sensitive facial skin. With dual blade mesh, it could remove the facial hair from the root softly and smoothly, make your facial skin looks fair and smooth. The dust-proof cover combines magnetic design, put on and take off the cover to control the switch. Built-in LED light makes it possible to use freely even in a dark environment.

3

► Indications

No.	Item	Indication
1	ON	Take off the magnetic cover or twist the rotation switch, the device starts to work, LED light up.
2	OFF	Put on the magnetic cover or twist the rotation switch, the device stop to work, LED light goes out.

► How to Use




1. Take off the magnetic cover or twist the rotation switch to turn it on.

4



2. Keep blade mesh close to skin and move against the direction of hair.



3. Put on the magnetic cover or twist the rotation switch to turn it off.




4. Clean inside hair storage area.
 (Please refer to Cleansing in Safety Precautions)

5

► Safety Precautions

Cautions

- ① Children are prohibited from using.
 ② Do not use if your skin has acne or scab.
 ③ Please keep the blade mesh dry and clean.
 ④ Do not move too much or use it for a long time.
 ⑤ Do not remove the blade mesh while it is working.



6